


220 - 240 V  
400 W

# concept


Tyčový mixér  
Tyčový mixér  
Blender ręczny  
Rod mixer

TM 4610, TM 4620


v.1.1






42390547 (3)



42390548 (4)



42390549 (5)





(6) 42390550

(7) 42390551

(1) 42390545

(2) 42390546





220 - 240 V  
400 W

# concept

Tyčový mixér  
Tyčový mixér  
Blender ręczny  
Rod mixer

TM 4610, TM 4620

v.1.1

## Seznam náhradních dílů TM 4610, TM 4620

CZ

1. Nástavec tyčový plast TM-4610	42390545	5. Nůž sekací TM-4620	42390549
2. Nástavec tyčový nerezový TM-4620	42390546	6. Převodovka metly kompletní TM-4620	42390550
3. Spojka TM-4610/4620	42390547	7. Metla šlehačí TM-4620	42390551
4. Víko s převodovkou kompletní TM-4620	42390548		

## Wykaz części zamiennych TM 4610, TM 4620

PL

1. Rozdrabniacz plastikowy TM-4610	42390545	5. Nóż siekający TM-4620	42390549
2. Rozdrabniacz metalowy TM-4620	42390546	6. Przycisk zwalniający trzepaczki TM-4620	42390550
3. Sprzęgło TM-4610/ TM-4620	42390547	7. Trzepaczka TM-4620	42390551
4. Wieko kompletne TM-4620	42390548		

## List of Spare Parts TM 4610, TM 4620

EN

1. Blend extender plastic TM-4610	42390545	5. Gear unit of the whisk assembly TM-4620	42390549
2. Blend extender stainless TM-4620	42390546	6. Chopper knife assembly TM-4620	42390550
3. Complete lid of chopper extender assembly TM-4620	42390547	7. Whisk TM-4620	42390551
4. Extender connector part TM-4610/4620	42390548		