







Návod pro instalaci
LKV8360, LKV9360




A (mm)	B (mm)	C (mm)	D (mm)
641.5	1210	1937	1939-1942




A


1




2







3







4












B











b

