










Návod pro instalaci
LKV9370







A (mm)	B (mm)	C (mm)	D (mm)
640	1223	1937	1939-1942







A














B











b

